

## PARTITION - PERFORATED FLEET - GM (NO PASS THROUGH DOOR)

Part #: 406GMF-P



## Partition - Perforated Fleet - GM (No Pass Through Door)

This partition has no pass through.

The product includes plus nuts required for installation. Consider purchasing our Plus Nut Tool (#P9902) if you don't already have a plus nut installation tool.

## Features:

- Comes with required wing kit to install into a Chevy Express van
- Not a pass-through door, cannot be used with 40620
- 18 gauge steel, to provide strength, security and reduce noise
- Corner contoured to prevent reaching in from the cab to unlock side door
- Quick and easy installation
- Matte powder coating minimizes glare and resists scratches and chipping
- · Perforated for increased visibility
- Holman warranty

## **Vehicle Fit:**

Chevy Express GMC Savana