

## **PARTITION - PERFORATED FLEET - GM (NO PASS THROUGH DOOR)**

---

**Part # : 406GMF-P**



### **Partition - Perforated Fleet - GM (No Pass Through Door)**

*This partition has no pass through.*

*The product includes plus nuts required for installation. Consider purchasing our Plus Nut Tool (#P9902) if you don't already have a plus nut installation tool.*

#### **Features:**

- Comes with required wing kit to install into a Chevy Express van
- Not a pass-through door, cannot be used with 40620
- 18 gauge steel, to provide strength, security and reduce noise
- Corner contoured to prevent reaching in from the cab to unlock side door
- Quick and easy installation
- Matte powder coating minimizes glare and resists scratches and chipping
- Perforated for increased visibility
- Holman warranty

#### **Vehicle Fit:**

Chevy Express  
GMC Savana

